


dacor

LET THE SHOW BEGIN

DHD30M967W S/M



DHD30M967W S/M



DHD30M967W S/M

ITEM NO.	PART NUMBER	DESCRIPTION
1	Not Serviceable	ASSY, 30X18IN CANOPY
2	702423	ASSY, CANOPY, MTG BRKT
3	702718	ASSEMBLY, BLOWER
4	702859	ASSY, 30IN LINER
5	703003	WELDMENT, INTERIOR PANEL
6	702871	ASSY, 30IN REAR LINER
7	702865	WELDMENT, 30IN GREASE TRAY
8	702493	ASSY, TERMINAL BLOCK PLATE
9	702967-01	ASSY, CONTROLLER
10	101613	COLLAR, DAMPER
11	109114	FRAME, SIDE
12	110148-01	TRIM, 30IN, LH
13	110148-02	TRIM, 30IN, RH
14	109071	HARNESS, MAIN WIRE, 1-FAN
15	83263	SCREW, PHILL, ROUND WASHER, HD.
16	83534	SCREW, #8 X .375, ENAMEL PANEL
17	102373	SCREW, #8-18 X 1/4"
18	83167	CLAMP, CABLE 3/4"
19	83056	BUSHING HEYCO SB-875-11
20	83308	6-32 KEPS NUT
21	83334	STARWASHER, #8
22	83035	NUT, WING, #10-24
23	83001	SCREW, PHIL PAN HD, 8 x 1/4"
24	83530	SCREW, PHIL. PAN HD, 4-40 X .625 LG
25	83531	NUT, HEX, KEPS 4-40
26	702855	ASSEMBLY, CONTROL BRACKET
27	110301	THERMISTOR
28	110493	WIRES, HOOD GROUND
29	102402	CUP WASHER
30	102403	SCREW, SLOT HEX, PHIL
31	110343	HARNESS, 2 LIGHT LED WIRE
32	109253	LIGHT, LED
33	702495	WELDMENT, BAFFLE
34	109109	KNOB, BAFFLE
35	109328	SCREW 8-32 X 5/16" PHIL PAN HD
36	83340	#10 LOCK WASHER
37	702848	CONTROL, NK9900
38	109355	TRIM, LAMP
39	101624	LAMP HOLDER