



The Life of the Kitchen.®

A faded background image of a Dacor electric range in a kitchen setting. The range is white with a stainless steel cooktop and a control panel. A white bowl sits on the cooktop, and various kitchen items are visible on the counter to the left and right.


**PARTS
CATALOG**

Electric Range Models DR30ES, DR30EFS, DR30EIS, DR30EIFS

Page #	Description
2	Cooktop Assembly
3	Control Panel Assembly
4	Door Assembly
5	Oven Cell Assembly
6	Outer Assembly
7	Outer Assembly Parts
8	Base Assembly
9	Miscellaneous

Revised 12-13-2013


DR30E Range Cooktop Assembly



Item	Part#	Description
1	100644	Spring, Heater
2	700411-08	Element, Dual
3	100811	Grommet, Bake Wires
4	105903	Element, 900/1800/2500W
5	105915	Indicator Light, 4 zone
6	105916	Bracket, Indicator Light
7	107120	Wire Harness, Cooktop (not shown)

Item	Part#	Description
8	107234	Shield, Indicator Light
9	36834	Gutter, Top Section
10	66128	Element, 1200W
11	66129	Element, 1500W
12	701621	Assy, Glass Panel
13	701622	Burner Chassis


DR30E Range Control Panel Assembly



Item	Part #	Description
1	107122-01	Knob, Single
2	107122-02	Knob, Double
3	107123-01	Knob, Triple
4	102377	Relay Board
5	106795	Spacer, Membrane
6	107113	Switch, Single Element
7	107114	Switch, Double Element
8	107115	Switch, Triple Element
9	107138	Bracket, Switch
10	107179	Wire Harness, Control Panel (not shown)
11	107206	Wire Harness, Relay Board (not shown)

Item	Part #	Description
12	701624	Sub-Panel
13	105995	Display Module
14	701284	Membrane Panel
15	83080	Washer, Nylon
16	83139	Spacer
17	83308	Nut, Keps
18	83181	Screw, Phil, 8-32 x 1
19	100122CH	Trim Ring
20	107125	Indicator Light (includes lens)
21	701828	Control Panel Assembly
22	83709	Screw, Trx Wfr Hd, #8 x 1/2"
23	83538	PCB Support (not shown)

DR30E Range Door Assembly



Item	External Handle Part #	Built-in Handle Part #	Description
1	701427-02 ¹	701697 ²	ASSEMBLY, DOOR SKIN
2	13659-001	NA	ASSEMBLY, DOOR HANDLE
3	72511CH	72511CH	LOGO, DACOR, 4", CHROME
4	107221B	107221B	HEAT SHIELD
5	105353	105353	INSULATION, SIDE DOOR
6	105352	105352	INSULATION, TOP DOOR
7	72711	72711	HINGE, LEFT
8	72710	72710	HINGE, RIGHT

Item	External Handle Part #	Built-in Handle Part #	Description
9	72968	72968	WINDOW PACK
10	100015	100015	GASKET, WINDOW PACK
11	701428-04 ³	701428-05 ³	ASSEMBLY, DOOR LINER
12	701430BP ⁴	701430BP ⁴	DOOR LINER
13	100026	NA	SCREW, #10-32 X 2.0, TORX
14	105510-01	105510-01	HINGE BRACKET COVER, RIGHT
15	105510-02	105510-02	HINGE BRACKET COVER, LEFT
16	83263	83263	SCREW, PHIL TRS, #8 X 3/8


¹ For complete door assembly, order part # 701426-03 which includes handle and Dacor logo on front.

² For complete door assembly, order part # 701698-02 which includes Dacor logo on front.

³ Pre-assembled, includes door liner, window pack with gasket, hinges, hinge covers, all insulation, heat shields and air deflectors.

⁴ Door liner alone.

DR30E Range Oven Cell Assembly



Item	Part #	Description
1	101339	Door Latch
2	72752	Temperature Sensor
3	102369	Broil, Element
4	700633 ¹	Convection Fan Motor ¹
5	107111 ²	Assy, Light, Halogen ²
6	72348	Receptacle, Hinge
7	105991	Latch Plate
8	105485	Smoke Eliminator, Top
9	105366	Gasket, Cell
10	106991	Support, Rack
11	106573	Bake, Element


¹ Includes fan blade, hex nut and washer

² Includes light bulb

Item	Part #	Description
12	105329BP	Convection Baffle
13	82891	Filter, Convection
14	107116	Duct, Smoke Eliminator
15	105919	Bake Pan
16	83618	Rubber Bumper
17	105917	Case Top
18	106976	Insulation, Broil, Top
19	106977	Insulation, Case Side
20	106978	Insulation, Case Back
21	107104	Insulation, Broil
22	36280	Mounting Plate, Conv Mtr
23	107105	Broil Pan
24	72717	Socket, Meat Probe

Item	Part #	Description
25	72755	Smoke Eliminator, Bot.
26	80168	Insulation, Conv. Motor
27	82377	Convection Element
28	107239	Holder, Bake Element
29	701680	Case Back
30	701692	Case Side, RH
31	701693	Case Side, LH
32	92321	Switch, Hi Limit
33		Not replaceable
34	83708	Screw, #8 x 1/2, Torx
35	83379	Screw, Slot, #8 x 1/2"
36	83709	Screw, Torx, #10 x 1/2", Black
37	83023	Screw, Slot, #10 x 3/8"

DR30E Range Outer Assembly



DR30E Range Outer Assembly Parts

Item	Part # Freestanding Units	Part # Slide-In Units	Description
1	701676-01 ¹	NA	Panel, Side, LH
	NA	701677-01 ²	Panel, Side, LH, 3 1/4"
2	701676-02 ¹	NA	Panel, Side, RH
	NA	701677-02 ²	Panel, Side, RH, 3 1/4"
3	105998	105998	Cover, Electrical
4	102554-02	102554-02	Power Cord, 50 Amp
5	105983	105983	Side Support, LH
6	105984	105984	Side Support, RH
7	105985	105985	Rear Panel, Top
8	105987	105987	Electrical Chassis
9	102384	102384	Terminal Block
10	102385-02 ³	NA	Adaptor, 1.125
11	105988	105988	Relay Board Support
12	105989	105989	Air Deflector, Cool Fan
13	105990	105990	Rear Exhaust, Right
14	105992	105992	Rear Cover
15	105993	105993	Cover, Cooling Fan
16	105997	105997	Box, Electrical
17	105999	105999	Corner, RR Cover
18	107117	107117	Box, Rear Panel
19	107119	107119	Cover, Relay
20	107118	107118	Heat Shield, Top Front
21	107202B	107202B	Grill, Intake
22	701659	701659	Panel, Kick
23	701715-02	701715-02	Backguard, 3"
	701715-01	701715-01	Backguard, 6"
	701715-03	701715-03	Backguard, 9"
24	701739-01	701739-01	Post Trim, LH
25	701739-02	701739-02	Post Trim, RH
26	82986	82986	Cooling Fan
27	NA	NA	Base (see page 8)
28	102403	102403	Ground Screw (not shown)


Item	Part # Slide-In Units	Description
29	83555	Screw, Washer, Fiber
30	83263	Screw, #8 x 3/8, Black
31	105737	Screw, #8 x 1 1/4
32	83023	Screw, Slot, #10 x 3/8"
33	83708	Screw, #8 x 1/2, Torx
-	107121	Wiring Harness, Main (not shown)
-	102403	Grounding Screw, #10 (not shown)
-	92191-01	Bushing, Split, .75 dia
-	92191-02	Bushing, Split, 1.0 dia
-	92191-03	Bushing, Split, 1.375 dia
-	92191-03	Bushing, Split, 1.375 dia

¹ Models DR30ES[-C], DR30EFS[-C]

² Models DR30EIS, DR30EIFS

³ Not used on models that end in -C


DR30E Range Base Assembly



Item	Part #	Description
1	83359	Leg
2	107212	Panel, Base
3	701724	Base Leg Rail
4	105922	Exhaust Plate
5	107210	Base Box

Item	Part #	Description
6	107213	Exhaust Deflector
7	83023	Screw, Slot #10 x 3/8
-	105733-02	Anti-Tip Bracket (not shown)
-	701555	Hardware Kit Anti-Tip Bracket (not shown)

DR30E Range Accessories



Item	Part #	Description
1	107112	Light Bulb, 120 Vac, 20 Watt
2	72723	Meat Probe
3	82499	Scraper, Ceran
4	A300	Cleaning Creme, Ceran
5	102402	Cup Washer
6	701464	GlideRack Oven Rack
7	106992	Standard Oven Rack