



FREEZER DOOR PART



Freezer Door Parts List

Reference #	Dacor Part#	Description
200A	109736	Assy, Freezer Door
202A	109738	Gasket Assy,Door
202B	109739	Stopper,Door
210C	109740	Bin Assy,Door
269F	109763	Cover,Lead Wire, Right
269G	109764	Connector
273A	109765	Bracket,Door,Upper Freezer
273C	109767	Bracket,Door, Lower Freezer
600A	109824	Ice Maker Assy,Kit
606A	109827	Motor, AC Indoor, Ice Maker
607A	109828	Holder Assy,Bracket, Freezer Door
610A	109829	Bucket Assembly,Ice
610B	109830	Trim, Ice Assy.
611B	109831	Cover, Ice Bucket
612A	109832	Motor, AC Dispenser, Ice Maker
B06	109876	Stopper,Handle


REFRIGERATOR DOOR PART



Refrigerator Door Parts List

Reference #	Dacor Part#	Description
230A	109741	Door Assy,Refrigerator
231A	109742	Door Foam Assy,Refrigerator
232A	109743	Gasket Assy,Door
232B		
241A	109744	Bin Assy,Door (Enclosed)
241C	109745	Bin,Window
241D	109746	Cap,Rubber
241E	109747	Bushing, Bin, door bin
246A	109748	Bin Assy,Door
246B	109749	Bin Assy,Door
247A	109750	Cover,Lever
247B	109751	Spring,Lever
247C	109752	Button,Lever
247D	109753	Roller Assy
247E	109754	Screw,Customized
247F	109755	Roller Assy
247G	109756	Button,Lever
247H	109757	Spring,Lever
247J	109758	Cover,Lever
253A	109759	Rail,Slide
273B	109766	Bracket,Door, Upper Fridge
273D	109768	Bracket,Door,Lower Fridge


FREEZER COMPARTMENT



Freezer Compartment Parts List

Reference #	Dacor Part#	Description
120B	109669	Shelf Assy,Refrigerator
120C	109670	Cover Assy,TV
125B	109699	Tray Assy,Drawer
126A	109700	Tray Assy,Drawer
126B	109701	Cover Assy,TV, Frzr
127A	109702	Tray Assy,Drawer
127B	109703	Tray,Drawer
127C	109704	Tray Assy,Drawer
127D	109705	Tray,Drawer
135B	109709	Duct Assy,Multi
135E	109710	Cover,Lamp
135F	109711	LED Assy
135J	109712	Cap,Duct
136A	109714	Fan Assy
136B	109715	Bracket,Motor
136C	109716	Damper,Motor Support
137B	109717	Shroud Assy,Freezer
138A	109718	Duct Assy,Multi, Frzr
153E	109725	Case Assembly,Lamp
153G	109726	LED Assy, Lamp Case
253B	109760	Holder,Shelf, Freezer
273E	109769	Bushing, Hinge
273F	109770	Hinge Assy,Upper Freezer
273G	109771	Bracket,Hinge, Upper Freezer
302B	109792	Evaporator Assy, Freezer
400A	109808	Controller Assy, Freezer
403A	109813	Motor,DC, Freezer
408A	109817	Heater,Sheath, Freezer
700A	109862	Trim, Freezer Side


REFRIGERATOR COMPARTMENT



Refrigerator Compartment Parts List

Reference #	Dacor Part#	Description
123M	109696	Holder Assy,Bracket
127E	109706	Tray Assy,Drawer
127F	109707	Tray,Drawer
127G	109708	Tray,Drawer
135E	109710	Cover,Lamp
135F	109711	LED Assy
135K	109713	Grille Assy,Fan
138B	109719	Duct,Multi
140A	109721	Shelf Assy,Refrigerator
152A	109722	Cover,Sensor
153A	109723	Case Assy,Display
153C	109724	LED Assy,Display Case
163C	109727	Tray Assy,Vegetable
163G	109728	Gasket,Home Bar
163J	109729	Cover Assy,Sealed Drawer
163M	109730	Rail,Slide, Left
163N	109731	Rail,Slide, right
163Q	109732	Tray Assembly,Vegetable
165A	109733	Tray Assembly,Drawer
165D	109734	Case Assy. Sealed Drawer
166A	109735	Cover Assy. TV textured
253C	109761	Holder,Shelf, Refrigerator
273E	109769	Bushing, Hinge
273H	109772	Hinge Assy,Upper Fridge
273J	109773	Bracket,Hinge, Upper Fridge
302C	109793	Evaporator Assy, Fridge
312B	109802	Tray,Drain
332D	109807	Bracket,Motor
400B	109809	Controller Assy, Fridge
408B	109818	Heater,Sheath, Fridge
622C	109845	Cover,Grille Fan
628L	109861	Bracket,Valve, Fridge
700B	109863	Trim, Rt. Side, Fridge


TOP PART



Top Part Parts List

Reference #	Dacor Part#	Description
402J	109811	Switch,Magnet, Left
402K	109812	Switch,Magnet, Right
410G	109819	Holder Assy,Bracket
500A	109820	PCB Assy,Main
502A	109822	Cover Assy,PCB
502B	109823	Case,PCB
701A	109864	Trim Upper Cabinet
701B	109865	Trim, Case
701C	109866	Cover, Upper Front


LOWER PART



Lower Part Parts List

Reference #	Dacor Part#	Description
103A	109667	Leg,Adjust
105B	109668	Cover,Lower
273K	109774	Hinge Assy,Lower Left
273L	109775	Hinge Assy,Lower Right
273M	109776	Hinge Assy,Lower Left
273N	109777	Hinge Assembly,Lower Right
273P	109778	Cam,Hinge
273Q	109779	Cam,Hinge
621C	109842	Connector,Tube, Lower
621D	109843	Connector,Tube, Lower
627A	109851	Holder,Pipe, Lower
627B	109852	Holder,Drier, Lower
627J	109853	Gasket,Foam, Lower
702A	109867	Tray Assy,Drip
703A	109868	Roller, Left Assy.
703B	109869	Roller, Right Assy.
704A	109870	Pan, Drain
705A	109871	Cover,Lock
705B	109872	Guide,Rail
705C	109873	Cover,Lock
706A	109874	Supporter,Housing
706B	109875	Supporter,Housing

MECHANICAL COMPARTMENT




Mechanical Compartment Parts List

Reference #	Dacor Part#	Description
300A	109789	Compressor,Set Assy
301A	109790	Condenser Assy,Wire
302A	109791	Guide,Fan
303C	109794	Overload Protect
304A	109795	Cover,PTC
306A	109796	Damper,Compressor
307A	109717	Stopper,Compressor
308B	109798	Guide,Fan
309A	109799	Fan Assy
310A	109800	Pipe,Joint
310B	109801	Pipe,Compressor Sealing
313A	109803	Cover Assy,Machinery(Rear)
317A	109804	Drier Assy
318A	109805	Guide,Air
319A	109806	Guide,Air
403B	109814	Motor,DC, Fan
619B	109837	Valve Assy,Gas

DYF42SBSIWS


DISPENSER PART



Dispenser Parts List

Reference #	Dacor Part#	Description
275A	109780	Cap Assy,Duct
276A	109781	Spring,Lever
276B	109782	Holder,Lever
279B	109785	Frame,Funnel
279H	109786	Button Assy
279J	109787	Lever,Dispenser
281A	109788	Tray, Dispenser
402C	109810	Switch,Micro
405A	109815	Motor,DC, Dispenser
501A	109821	Cover Assy,Display
616G	109834	Tube Assy,Inject, Dispenser
616J	109835	Tube Assy,Inject, Dispenser
619D	109839	Valve,Water, Dispenser
621A	109840	Connector,Tube, Dispenser
621B	109841	Connector,Tube, Dispenser


FREEZER RAIL PART



Freezer Rail Parts List

Reference #	Dacor Part#	Description
122A	109671	Guide,Rail, Rt. Freezer
122B	109672	Guide Assy,Rail
122C	109673	Guide,Rail
122D	109674	Guide Assy,Rail
122E	109675	Guide,Rail
122F	109676	Guide Assy,Rail
122G	109677	Guide,Rail
122H	109678	Guide Assy,Rail
123A	109685	Guide,Rail
123B	109686	Rail,Slide
123C	109687	Holder Assy,Bracket
123D	109688	Guide,Rail
123E	#N/A	Rail,Slide
123F	109690	Rail,Slide
123G	109691	Guide,Rail
123H	109692	Rail,Slide
123J	109693	Guide,Rail

REFRIGERATOR RAIL PART




Refrigerator Rail Parts List

Reference #	Dacor Part#	Description
122J	109679	Guide,TV
122K	109680	Guide Assy,Rail
122L	109681	Guide,Rail
122M	109682	Guide,TV
122N	109683	Guide Assy,Rail
122Q	109684	Guide Assy,Rail, Left Fridge
123K	109694	Guide,Rail
123L	109695	Rail,Slide
123M	109696	Holder Assy,Bracket
123N	109697	Rail,Slide
123P	109698	Guide,Rail

DYF4SBIWS

REFRIGERATOR RAIL PART



Refrigerator Rail Parts List

Reference #	Dacor Part#	Description
603B	109825	Holder,Bracket
603C	109826	Clip
615A	109833	Tank,Water
619A	109836	Valve Assy,Water
619C	109838	Bracket,Valve
621E	109844	Connector Assy, Water Valve
624A	109846	Filter Assy,Water
624C	109847	Cover,Filter
624E	109848	Cap Assy,Head
624G	109849	Filter,Head
626A	109850	Cover,Filter
628A	109854	Tube Assy,Inject, Water Line
628B	109855	Tube Assy,Inject, Water Line
628E	109856	Insulation,Pipe
628F	109857	Insulation,Pipe
628H	109858	Gasket,Foam
628J	109859	Tube Assy,Inject, Left
628K	109860	Tube Assy,Inject, Right
--	EDR3RXD1	Water Filter
--	242294402	Filter Plug