


REFRIGERATOR

MODELS:

DYF42BIWS10 (Stainless Steel)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	14	489399	Screw	33	W10485630	Screw
	W10683772	Use and Care Guide	15	3400230	Screw	34		Bracket, Support Base (Front)
	W10703426	Energy Guide	16	2257644	Hinge, Top		2006616	Left Hand
	2306424	Icemaker and Ingredient Care Center Service Sheet	17	W10674648	Bracket, Filter		2006556	Right Hand
	2220407	Modular Icemaker Service Sheet	18	W10001250	Screw	35	1157158	Screw
	W10683771	Installation Instructions	19	2004994	Lock, Bushing	36	2006617	Bracket, Base Support (Rear)
2		Cabinet (Not A Serviceable Part)	20	W10484913	Bushing, Top Hinge	37	2006346	Washer, Extension Arm
3		Button, Water Filter	21	W10663352	Clip	38	2316859	Bushing, Extension Arm
	2260503B	Black	22	2221242	Spring, Door Closure (Green)	39	1163283	Screw
4	W10138054	Assembly, Roller	23	486194	Screw	40	W10271541	Connector, Union
5		Assembly, Leveler Support	24	2005008	Ring, Bushing Retaining	41	8281163	Screw (Stainless)
	W10138423	Right Hand	25	W10129069	Clip, Wire	42		Switch, Rocker Arm
	W10279275	Left Hand	26	W10482554	Cover, Bottom Gap		1118894	Switch, Rocker Arm
6		Cap, Water Filter	27		Hinge, Bottom		1115373	Switch, Rocker Arm Combination (Freezer)
	2260518B	Black		2006780	Right Hand	43	2215938	Cover, Switch
7	2307640	Bracket, Grill Mounting		2006779	Left Hand	44	487415	Screw
8	2307584	Grommet, Crossover Tube	28	2302876	Bushing, Adjustable	45		Bracket, Switch
9	2320509	Stop, Door	29	8533913	Screw		2221097	Right Hand
10	W10121140	Housing, Water Filter	30		Skirt, Bottom Grille		2221096	Left Hand
11	2318189	Tray, Filter Drip		W10188549	Skirt, Grille (Bottom)	46	2215612	Cover, Air Duct
12	3400525	Screw	31		Arm, Door Closer Extension	47	2005032	Leveler, Adjustable
13	W10565739	Filter, Water		2266882	Right Hand	48	2314064	Tube, Drain
				2266881	Left Hand			
			32		Grille, Bottom			
				W10182717	Black			


CABINET TRIM PARTS



CABINET TRIM PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Trim, Cabinet Side (Right)	4	486194	Screw	7	W10121451	Insert, Blind Threaded
	W10132472	Aluminum	5		Trim, Top Cabinet	8	2005925	Seal, Side Trim
2	1163283	Screw		2314017	Aluminum	9	W10001250	Screw
3		Trim, Bottom	6		Trim, Cabinet Side (Left)			
	2316687	Aluminum		W10132541	Aluminum			


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	11	W10237018	Valve, Release	20	2188820	Thermistor
2	2306010	Thermistor	12	2310205	Assembly, Meat Pan Wire	21	W10475010	Assembly, Spacer
3	2208970	Duct, Air	13	8533929	Screw (Stainless)	22	2309087	Cover, Air Diffuser
4	2259077	Ladder, Shelf	14	486194	Screw	23	2003577	Guard, Air Return
5	520965	Support, Ladder	15	2221296	Assembly, Air Baffle	24	2259398	Seal, Air Duct
6	2006475	Screw (White)	16	W10645131	Reservoir, Water	25	W10159487	Diverter, Crisper Cover
7	487539	Screw (Stainless)	17	W10141518	Screw			
8	2302937	Thermistor	18	2309222	Assembly, Air Diffuser			
9	2302986	Lid, Baffle	19	2317844	Assembly, Thermistor			
10	W10169528	Assembly, Control Baffle						






FREEZER LINER AND AIR FLOW PARTS



FREEZER LINER AND AIR FLOW PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10436861	Motor, Fan	19	W10151205	Cover, Emitter	35	2306010	Thermistor
2	2198665	Tube, Circuit Board	20		Liner (Not A Serviceable Part)	36	2317105	Cover, Thermistor
3	2169142	Blade, Fan	21	2259025	Cover, Air Outlet	37	2006475	Screw (White)
4	W10260421	Retainer, Fan Motor	22	2307751	Shield, Light	38	2259032	Ladder, Shelf
5	2302817	Gasket, Scroll Assembly	23	W10428000	Cover, Evaporator	39	2259445	Support, Ladder
6	W10321090	Grommet, Motor	24	2302850	Support, Air Duct	40	2198634	Pin, Door
7	486194	Screw	25	487539	Screw (Stainless)	41	W10193840	Board, Emitter Circuit
8	2259464	Wedge, Right Air Duct	26	2198635	Spring, Door	42	2198633	Flipper, Shut Off
9	W10141604	Screw	27	2309283	Deflector, Air Duct	43	2315398	Slide, Icemaker Shut Off
10	W10191429	Socket, Light	28	1112260	Support, Evaporator	44	W10290817	Board, Receiver Circuit
11	489348	Clamp, Tube	29	W10173127	Assembly, Shelf Stud	45	W10160570	Bi-Metal, Defrost
12	2326255	Bulb, Light	30	W10191952	Screw	46	W10142283	Screw (White)
13	489214	Screw	31		Rail, Evaporator Cover	47	W10581992	Assembly, Evaporator Cover
14	2182120	Scroll, Fan		2221107	Left Hand	48	W10581988	Gasket, Evaporator Cover
15	2259465	Wedge, Left Air Duct		2259355	Right Hand			
16	2307774	Duct, Air	32	2220904	Gasket, Evaporator Cover			
17	2198643	Lens, Receiver	33	W10151208	Cover, Receiver			
18		Block, Fan Scroll	34	W10482187	Harness, Bi-Metal Wire			
	2209480	Right Hand						
	2209066	Left Hand						


MOTOR AND ICE CONTAINER PARTS



MOTOR AND ICE CONTAINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10395653	Assembly, Ice Container	4	2198628	Seal	8	2318028	Cover
2	8281163	Screw (Stainless)	5	2318082	Shaft, Drive	9	2315559	Sleeve, Bearing
3	2188919	Clip, Shaft	6	2318011	Enclosure, Motor			
			7	2315547	Motor, Dispenser			


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10691197	Control Box Assembly	5	2307595	Shield, Control Box	8	W10191429	Socket, Light
2	2317000	Clip, Control Box	6	487539	Screw (Stainless)	9	2326255	Bulb, Light
3	W10458299	Wire, Jumper	7	W10151210	Board, Ingredient Care Center Display	10	8281251	Screw (White)
4	2307592	Bracket, Control Box						


REFRIGERATOR SHELF PARTS



REFRIGERATOR SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10556777	Assembly, Shelf	11	2252255	Trim, Side Glass Crisper	16		Screw
2	2179404	Rack, Wine	12	2256250	Trim, Side Glass Meat Pan		8533929	Screw (Stainless)
3	W10556312	Assembly, Meat Pan Cover	13		Spacer, Crisper			Left Hand
4	W10556775	Assembly, Crisper Cover		2256222	Right Hand		8533928	Screw (Stainless)
5	2257582	Trim, Glass (Rear)		2256223	Left Hand	17	W10407627	Assembly, Meat Pan
6	W10407624	Pan, Crisper	14		Slide, Crisper	18	2256366	Front, Meat Pan
7		Slide, Meat Pan		2302956	Left Hand			
		2302954		2302957	Right Hand			
		2302955	15		Spacer, Meat Pan			
8	2302831	Trim, Glass (Front)		2256243	Left Hand			
9	2256254	Trim, Glass (Rear)		2256244	Right Hand			
10	2256248	Front, Crisper Pan						

FREEZER SHELF PARTS




FREEZER SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10175905	Shelf, Wire
2	2302883	Shelf, Fixed
3	2259082	Basket, Freezer
4	2256270	Front, Basket

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5		Slide, Basket
	2259317	Right Hand
	2259318	Left Hand
6	8533928	Screw (Stainless)


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10193490	Door, Refrigerator	11	W10168981	Mount, Handle	20		Cap, End
2	W10127710	Plate, Handle Door	12	2309060	Spacer, Handle Side Door		W10323172	Right Hand
3	W10485980	Assembly, Top Hinge	13	488568	Screw (Stainless)		W10323173	Left Hand
4	2316804	Spacer, Door Hinge Bottom	14	8281250	Screw (Stainless)	21	W10323036	Bin, Center Utility
5	W10162602	Screw	15	2005433	Spacer, Door Skin (Top)	22	2257616	Door, Utility Bin
6	2302878	Assembly, Bottom Hinge	16	308544	Screw	23	W10323599	Bin, Shallow Door
7	2222796	Rail, Lid	17	W10142296	Spacer, Hinge Side Door	24	W10323747	Bin, Gallon Door
8	2222982	Gasket, Utility Bin	18	2004934	Spacer, Door Skin Bottom			
9	W10694211	Gasket, Door	19	W10127977	Filler, Door			
10	W10523728	Skin, Door Stainless						


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10646479	Door, Freezer	8	2309060	Spacer, Handle Side Door	14	W10142296	Spacer, Hinge Side Door
2	2302879	Assembly, Bottom Hinge	9		Skin, Door	15	308544	Screw
3	W10162602	Screw		W10561670	Stainless	16		Filler, Door
4	W10485980	Assembly, Top Hinge	10	8281250	Screw (Stainless)		W10159585	Top
5	2316804	Spacer, Door Hinge Bottom	11	2005433	Spacer, Door Skin (Top)		W10159582	Bottom
6	2222814	Gasket, Door	12	488568	Screw (Stainless)	17	W10127710	Plate, Handle Door
7	W10168981	Mount, Handle	13	2257385	Spacer, Door Skin Bottom	18	W10323602	Bin, Shallow


DISPENSER PARTS



DISPENSER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)	7		Housing, Middle (Not Available Order Item 8)	11	2305219	Cover, Control
2	486194	Screw	8	W10260622	Assembly, Housing	12	2321746	Assembly, User Interface Control Cover
3	W10546285	Assembly, Motor and Bracket	9		Pad, Water	13	W10553816	Assembly, User Interface
4	W10504458	Door, Ice		2305307GN	Universal Silver	14		Assembly, Drip Tray
5	2305235	Assembly, Spigot	10		Pad, Ice		2318062US	Universal Silver
6	2318017	Assembly, Separator		2305306GN	Universal Silver	15	2305342	Assembly, LED


TOP GRILLE AND UNIT COVER PARTS



TOP GRILLE AND UNIT COVER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Assembly, Top Grille	4	2256466	Panel, Unit Back	8		Nameplate
	W10560589	Stainless	5	W10694109	Cover, Unit Front		W10560583	Stainless
2	W10545068	Cover, Unit	6	487415	Screw	9	489348	Clamp, Tube
3	486194	Screw	7	W10167456	Assembly, Light Switch Wire	10	2215910	Grommet, Flexible


UPPER UNIT PARTS



UPPER UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10645666	Assembly, Inverter Box	15	1157158	Screw	32	W10525175	Cover, Condenser Top
2	489473	Screw	16	W10591457	Condenser	33	2310251	Cord, Power
3	W10653005	Compressor	17	W10427091	Assembly, Unit Wire	34	W10321055	Bracket, Control Assembly
4	W10321056	Housing, Control Board	18	2310207	Assembly, Condenser Fan Wire	35	487294	Screw
5	2318054	Control, Electronic	19	W10587113	Grommet	36	2266802	Switch, Power Disconnect
6	1100826	Grommet	20	4389107	Tie, Wire			Following Parts Not Illustrated
7		Support, Condenser	21	W10175593	Drier		978025	Valve, Access
	W10525179	Right Hand	22	W10414681	Bracket, Fan Motor		978026	Valve, Access
	W10525177	Left Hand	23	2188875	Motor, Condenser		978027	Valve, Access
8	W10648264	Tube, Heat Loop Transition	24	W10139483	Blade, Fan		978028	Valve, Access
9	2215676	Cover, Terminal	25	W10415670	Orifice, Fan		978029	Valve, Access
10	W10483905	Jumper, Inverter	26	W10146359	Screw		978030	Valve, Access
11	W10200659	Control, Electronic	27	2259350	Board, Power Supply		876764	Valve, Access
12	2203075	Spacer	28	W10356040	Control, Electronic			REFRIGERANT CHARGE
13	2256328	Bracket, Inverter Mounting	29	W10624944	Tube, Drier Transition			6.75 oz. (R-134A)
14	W10495645	Ground, Inverter	30	W10528578	Tube, Process			
			31	486194	Screw			


LOWER UNIT AND TUBE PARTS



LOWER UNIT AND TUBE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	2215648	Dampener	9	W10499596	Tube, Discharge	18	2320554	Support, Drain Pan
2	486194	Screw	10	2188820	Thermistor	19	W10160981	Assembly, Air Return Bracket
3	W10157752	Bracket, Heater	11	W10427992	Evaporator	20	2169104	Sealer, Insulation
4	W10648568	Tube, Oil Trap Suction	12	W10140161	Heater, Defrost	21	304392	Screw
5	W10388653	Tube, Transition (Drier/Restrictor)	13	1113048	Clamp, Heater	22	W10413009	Grommet, Air Return
6	W10281063	Assembly, Drain Pan	14	W10139908	Cover, Evaporator Seal			
7	W10309012	Cover, Wiring	15	W10432308	Gasket, Evaporator			
8	W10321048	Cover, Wire Box	16	2155774	Tie, Wire			
			17	W10169509	Clip, Heat Exchanger			

ICEMAKER PARTS



ICEMAKER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	2320601	Shield, Water Valve	15	W10141604	Screw	27	W10504753	Cover, Icemaker
2	W10508659	Assembly, Icemaker Wire	16	628228	Assembly, Mold and Heater (Also Order 542638)	28	W10223929	Assembly, Module and Motor
3	628379	Clip, Thermal Fuse	17		Motor, (Not Serviceable Order Item 28)	29	489136	Screw
4	W10296807	Tube, Filter Inlet	18	W10272168	Cup, Water Fill	30	W10141645	Screw
7	W10437853	Tube, Filter Outlet	19	627843	Ejector	31	486194	Screw
8	W10159842	Valve, Inlet	20	W10272161	Stripper, Ice	32	2252228	Bracket, Icemaker Mounting
9	2221070	Clamp, Tube	21	2194712	Support, Housing	33	304392	Screw
10	2320559	Support, Valve	22	2315522	Retainer, Thermostat	100	W10277448	Complete Icemaker Assembly
11	2198641	Bracket, Icemaker Cover	23	W10290336	Thermostat			
12	2208136	Clip, Water Tube	24	W10001280	Screw			
13	W10357286	Fitting, Water	25	W10279391	Assembly, Smart Valve Wire			
14	W10289690	Cover, Icemaker	26	489276	Screw			

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	511873	White Porcelain (2 oz.)
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White

MISCELLANEOUS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	20000008	Cleaner, Stainless Steel
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector

TORX SCREW WRENCH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key