


# ***dacor***

LET THE SHOW BEGIN

## **DYRTP36**




## Top Frame




Item	Part #	Description
1	107950BP	Spill Tray, Black Porcelain
2	702035	Grate, 4 Finger, 11 1/4"x23"
3	112089	Assy, Base, 16K
4	701985-01	Assy, Dual Burner, 18K, LP
5	701985-02	Assy, Dual Burner, 18K, LP
6	701985-03	Assy, Dual Burner, 18K, NGH
7	701985-04	Assy, Dua Burner, 18K, LPH
8	702186	Pack, Burner Ring/Burner
9	100703	Pack, Burner Ring/Cap/Base, 18K BTU
10	700017	Brass Ring M22x1
11	700145	Gasket, Dual Burner, Graphite

## Control Panel



Item	Part #	Description
1	702058E	Control Panel
2	107762S	Ring, Trim
3	107761-01	Knob, Illuminated, Simmer
4	107761-02	Knob, Illuminated, Griddle
5	83709	Screw, #8x1/2", Torx, Blk Oxide

# Cooktop Gas Tubing



Item	Part #	Description
1	107963-01	Support, Upper, LH
2	107963-02	Support, Upper, RH
3	72634	Re-ignition Module
4	102159	Plate Cover, Manifold Hole
5	107976	Enclosure, Igniter
6	108379	Set, Igniter wire
7	100900	S.S. Flex tubing 3/16x16, M./M.
8	100579	S.S. Flex tubing 5/16x18, M./M.
9	100900	S.S. Flex tubing 3/16x16, M./M.
10	100578	S.S. Flex tubing 5/16x21, M./F.
11	100900	S.S. Flex tubing 3/16x16, M./M.

Item	Part #	Description
12	100788	Flex Tubing 3/16", MXM 23"
13	100900	S.S. Flex tubing 3/16x16, M./M.
14	100900	S.S. Flex tubing 3/16x16, M./M.
15	100579	S.S. Flex tubing 5/16x18, M./M.
16	83023	Screw, Slot HWH, #10x3/8
17	83001	Screw, Phil Pan HD, 8x14"
18	108376	Wire Harness, Cooktop
19	108377	Wire Harness, Cooktop
20	108253	Support, Side, Upper
21	107964	Support, Spill Tray

