


dacor

LET THE SHOW BEGIN

DYRTP48




Top Frame




Item	Part #	Description
1	107773BP	Spill Tray, Black Porcelain
2	101524	Grate, 4 Finger, 14"x23"
3	112089	Assy, Base, 16K
4	701985-01	Assy, Dual Burner, 18K, NG
5	701985-02	Assy, Dual Burner, 18K, LP
6	701985-03	Assy, Dual Burner, 18K, NGH
7	701985-04	Assy, Dual Burner, 18K, LPH
8	702186	Pack, Burner Ring/Burner
9	100703	Pack, Burner
10	700017	Brass Ring M22x1
11	700145	Gasket, Dual Burner, Graphite

Control Panel



Item	Part #	Description
1	702131E	Control Panel
2	107761-01	Knob, Illuminated, Simmer
3	107761-02	Knob, Illuminated, Griddle
4	107762S	Ring, Trim
5	83709	Screw, #8x1/2", Torx, Blk Oxide

Cooktop Gas Tubing



Item	Part #	Description
1	107873-01	Support, Upper, LH
2	107873-02	Support, Upper, RH
3	72634	Re-ignition Module
4	102159	Plate Cover, Manifold Hole
5	108238	Box, Enclosure, Igniter
6	108379	Set, Igniter Wire
7	83533	Washer, .88OD x.165ID
8	108380	Wire Harness, 110 Vac Line
9	83023	Screw, Slot HWH, #10x3/8
10	83263	Screw, Phil, Round Washer, HD.
11	83001	Screw, Phil Pan HD, 8x14"
12	100580	S.S. Flex tubing 3/16x18, M./M.
13	100579	S.S. Flex tubing 5/16x18, M./M.

Item	Part #	Description
14	100579	S.S. Flex tubing 5/16x18, M./M.
15	100579	S.S. Flex tubing 5/16x18, M./M.
16	100900	S.S. Flex tubing 3/16x16, M./M.
17	100900	S.S. Flex tubing 3/16x16, M./M.
18	100900	S.S. Flex tubing 3/16x16, M./M.
19	100900	S.S. Flex tubing 3/16x16, M./M.
20	100900	S.S. Flex tubing 3/16x16, M./M.
21	108231	S.S. Flex tubing 5/16x14.5, M./M.
22	108376	Wire Harness, Cooktop
23	108377	Wire Harness, Cooktop
24	107876	Support, Spill Tray
25	107979	Shield, Heat
26	108232	S.S. Flex tubing 5/16x14.5, M./F.

