



The Life of the Kitchen.®



ECC Series Cooktops

IMPORTANT: This product may have some parts that are **No Longer Available (NLA)**. If the part you need is no longer available, please contact Dacor for a possible solution:

DACOR CARES PROGRAM NLA Part Locator Service

Customer Contact Number:

(800) 793-0093 ex. 2813
Hours: 6:00 AM - 5:00 PM Pacific Time

Service Agent/Technician Contact Number:

(800) 793-0093 ex. 3814
Hours: 7:00 AM - 4:00 PM Pacific Time

Web Inquiries: www.dacor.com/dacorcares **Email Inquiries:** dacorcares@dacor.com

Please provide the following information:


- Your name and phone number
- Product model number
- Product serial number
- The part number(s) you need

Page #	Description
2	ECC36 Cooktop Assembly
3	ECC46 Cooktop Assembly

ECC36 Cooktop Assembly

REF #	PART #	DESCRIPTION
1	82936	KNOB - ALMOND
*	82903	KNOB - BLACK
*	82904	KNOB - WHITE
2	83528	PANEL MOUNT HEX NUT
3	82546A,B,W	CONTROL PANEL GLASS
4	27347AP, BP, WP	TOP FRAME
5	83052	BRASS HEX NUT 3/8-24 UNF
6	83226	INDICATOR LIGHT
7	26162A, B, W	CONTROL PANEL
8	82513	SWITCH, 15A, 240VAC
9	12278	CHASSIS ASSEMBLY
10	83250	FEMALE CERAMIC CLIP
11	13020	FEMALE CERAMIC BLOCK
12	13103	CHASSIS COVER ASSEMBLY

Part no longer available? Call Dacor: (800) 793-0093 ex. 3814



ECC46 Cooktop Assembly

REF #	PART #	DESCRIPTION
1	82936	KNOB - ALMOND
*	82903	KNOB - BLACK
*	82904	KNOB - WHITE
2	83528	PANEL MOUNT HEX NUT
3	82547A,B,W	CONTROL PANEL GLASS
4	27343AP,, S BP, WP	TOP FRAME
5	83052	BRASS HEX NUT, 3/8-24 UNF
6	83226	INDICATOR LIGHT
7	26167A,B,W	CONTROL PANEL
8	82513	SWITCH, 15A. 240VAC
9	83250	FEMALE CERAMIC CLIP
10	13020	FEMALE CERAMIC BLOCK
11	83188	TERMINAL BLOCK
12	12279	CHASSIS ASSEMBLY
13	13104	CHASSIS COVER ASSEMBLY

Part no longer available? Call Dacor: (800) 793-0093 ex. 3814

