


CABINET PARTS

For Model: EF42NBSS03
(Stainless Steel)

42" BUILT IN
REFRIGERATOR



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Model: EF42NBSS03


(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	10	2209022	Housing, Water Filter	30		Grille Bottom, Front
	W10303784	Use & Care Guide					2209428B*	Black
	W10205629	Energy Guide	11	3400525	Screw			
	W10180102	Service & Wiring Sheet	12	W10168990	Filter, Water	31	W10004850	Screw
	2306337	Icemaker and Ingredient Care Center Service Sheet	13	489399	Screw	32		Bracket, Support Base (Front)
	W10180891	Main Control Service Sheet	14	2005378	Screw, Door Stop		2006616	(LH)
	W10379135	Installation Instructions	15	2257644	Hinge (Top)		2006556	(RH)
			16	W10348781	Bracket, Mount (Water Filter)	33	1157158	Screw
			17	W10001250	Screw	34	2006617	Bracket, Support Base (Rear)
			18	W10451421	Lock, Adjustable Bushing	35	2006346	Washer
2		Cabinet (Not A Serviceable Part)	19	2300082	Bushing	36	2316859	Bushing, Extension Arm
3	2209090	Clamp, Filter Housing	20	2221242	Spring, Door Closure	37	1163283	Screw
4	W10138054	Roller, Front & Rear	21	486194	Screw	38	8281163	Screw
5		Support, Leveler Assembly	22	2005008	Retaining Ring, Adjustable Bushing	39	2005032	Leveler, Assy Switch, Rocker Arm
	W10138423	Refrigerator Side	23	W10129069	Wire Clip		1118894	Refrigerator Door Side
	W10279275	Freezer Side	24	W10406421	Gap, Cover Assembly (Bottom)		1115373	Freezer Door Side
6		Cap, Water Filter	25		Hinge (Bottom)	41	2215938	Cover, Switch
	2186494B	Black		W10424756	Freezer Side	42	487415	Screw
7	2325157	Bracket, Grill Mounting		W10424754	Refrigerator Side	43		Bracket, Switch
8	2307584	Grommet, Crossover Tube	26	2302876	Bushing, Adjustable		2221097	(RH)
9	2005783	Cam, Door Closer	27	8533913	Screw 1/4-20 x 5/8		2221096	(LH)
			28		Skirt-Grille, Bottom	44	2215612	Cover, Rear
				2209025B	Black	45	2006841	Ring, Retainer
			29		Extension Arm, Door Closer	46	2307857	Cam Assembly
				2266882	(RH)	47	W10167456	Wire Assembly RC/FC Light Switch

* Some units are equipped with a (not shown) to allow access to the switch behind. Replace this type of grille with part number 2325185B.

CABINET TRIM PARTS

For Model: EF42NBSS03
(Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	W10132472	Cabinet, Trim (Right Side)
3	1163283	Screw
4	2316687	Cabinet, Trim (Bottom)
5	486194	Screw
6	2314017	Cabinet, Trim Top
7	W10132541	Cabinet Trim (Left Side)
8	W10121451	Nutsert
9	2005925	Seal-Trim, Side
10	W10001250	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER SHELF PARTS

For Model: EF42NBSS03
(Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

1	W10175905	Wire, Shelf
2	W10213534	Cover, Shelf
3	2302883	Shelf, Fixed
4	2259082	Basket
5	2256270	Front, Basket
6	2259317 (RH) 2259318 (LH)	Slide, Basket
7	8533928	Screw
8	2266934	Door, Ice
9	2266931	Bucket, Ice
10	2266955	Spacer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR LINER PARTS

For Model: EF42NBSS03
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


REFRIGERATOR LINER PARTS

For Model: EF42NBSS03
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2306010	Thermistor
3	2208970	Air Duct
4	2003577	Guard, Air Return
5	2259077	Ladder, Shelf
6	520965	Screw Support, Ladder
7	2006475	Screw
8	487539	Screw
9	2302937	Thermistor
10	2302986	Lid, Air Baffle
11	W10169528	Baffle, Control Assembly
12	2317844	Thermistor Assy
13	2310205	Jumper, Air Baffle
14	487539	Screw
15	486194	Screw
16	2221296	Air Baffle Assembly
17	2309222	Diffuser Assembly
18	2317105	Cover, Thermistor
19	2188820	Thermistor
20	2302992	Spacer, Air-Baffle
21	2309087	Cover, Diffuser
22	2259412	Seal, Air Duct (Round Hole)
23	2259398	Seal, Air Duct (Square Hole)
24	W10159487	Diverter, Crisper Cover

CONTROL PANEL PARTS

For Model: EF42NBSS03
(Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	2302772	Control Box
2	2215670	Insert, Control Box
3	2310197	Wire Assembly
4	106428	Circuit Board, Housing Control
5	2221121	Support, Control Box
6	487539	Screw
7	W10151210	Display Board, Ingredient Care Center
8	2162085	Socket, Light
9	W10311505	Light Bulb
10	W10142283	Screw
11	W10165030	Overlay, Control Box
12	2302717	Shield, Light
13	486194	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP GRILLE AND UNIT COVER PARTS

For Model: EF42NBSS03
(Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

- | | | |
|---|-----------|-------------------|
| 1 | W10162620 | Panel, Decorative |
| 2 | W10161693 | Cover, Unit |
| 3 | 486194 | Screw |
| 4 | 2256466 | Back Panel |
| 5 | W10185625 | Cover, Unit Front |
| 6 | 12989001 | Nameplate |
| 7 | 489399 | Screw |
| 8 | 2215910 | Grommet |

REFRIGERATOR SHELF PARTS

For Model: EF42NBSS03
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS

For Model: EF42NBSS03
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	W10165103	Shelf Assy
2	W10165091	Meat Pan Cover Assembly
3	W10165085	Crisper Cover Assembly
4	W10407624	Crisper Pan
5		Slide, Meat Pan
	2302954	(LH)
	2302955	(RH)
6	2256248	Front, Crisper Pan
7		Spacer, Crisper
	2256222	(RH)
	2256223	(LH)
8		Slide, Crisper
	2302957	(RH)
	2302956	(LH)
9		Spacer, Meat Pan
	2256243	(LH)
	2256244	(RH)
10	8533929	Screw
11	W10407627	Pan Assembly Meat
12	2256366	Front, Meat Pan


FREEZER LINER AND AIR FLOW PARTS

For Model: EF42NBSS03
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	2259385	Fan Motor
2	2169142	Fan Blade
3	2223733	Retainer, Fan Motor
4	2302817	Gasket, Cover
5	W10449920	Grommet
6	486194	Screw
7	2259464	Wedge, Air Duct
8	W10141604	Screw, Ground
9	W10191429	Socket, Light
10	2221070	Clamp, Nylon
11	2326255	Light Bulb
12	2182120	Scroll, Fan
13	2259465	Wedge, Air Duct
14	2266801	Deflector, Air
15	2307777	Air Duct
16	2209480	Block, Fan Scroll (RH)
	2209066	(LH)
17		Liner (Not A Serviceable Part)
18	2259025	Cover, Air Outlet
19	2307751	Light Shield
20	W10428000	Cover, Evaporator
21	8281163	Screw
22	2302850	Support, Air Duct
23	2309283	Deflector, Air Duct
24	1112260	Support, Evaporator
25	W10173127	Shelf, Stud
26	W10191952	Screw
27		Evaporator, Cover Rail
	2221107	(LH)
	2259355	(RH)
28	2220904	Gasket Evaporator Cover
29	W10139189	Harness, Evap Fan (Includes Item 36)
30	W10267707	Insulation, Sound
31	2188820	Thermistor
32	2317105	Cover, Thermistor
33	2006475	Screw
34	2259032	Ladder, Shelf
35	2259445	Support, Screw
36	W10160570	Defrost, Bi-Metal
37	W10142283	Screw
38	2317844	Thermistor Assy

REFRIGERATOR DOOR PARTS

For Model: EF42NBSS03
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


REFRIGERATOR DOOR PARTS

For Model: EF42NBSS03
(Stainless Steel)

Illus.	Part	
No.	No.	DESCRIPTION
1	W10193490	Refrigerator Door (Includes #9)
3	2266854	Hinge Assembly, Top
4	2316804	Spacer-Door, Top & Bottom
5	W10162602	Screw
6	2302878	Hinge Assembly, Bottom
7	2222796	Rail, Lid
8	2222982	Gasket, Utility Bin
9	2222811	Door Gasket, Magnetic
10	W10159605	Skin, Door
11	W10127710	Plate, Door Handle
12	2309060	Spacer, Door (Handle Side)
13	488568	Screw
14	8281250	Screw, 8-15 x .500 Stainless Steel
15	2005433	Spacer, Door-Skin (Top)
16	W10142296	Spacer, Door (Hinge Side)
17	2004934	Spacer, Door-Skin (Bottom)
18	W10127977	Filler, Door
19		End Cap (RH)
	W10323172	(LH)
20	W10323036	Bin, Utility Center
21	2257616	Door, Utility Bin
22	W10323599	Bin, Door
23	W10323747	Bin, Gallon
24	W10168981	Stud, Handle
25	308544	Screw

FREEZER DOOR PARTS

For Model: EF42NBSS03
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


FREEZER DOOR PARTS

For Model: EF42NBSS03
(Stainless Steel)

Illus.	Part	
No.	No.	DESCRIPTION
1	W10193486	Freezer Door
2	2302879	Hinge, Bottom
3	W10162602	Screw
4	2266854	Hinge, Top
5	2316804	Spacer-Door, Top & Bottom
6	2222814	Door Gasket, Magnetic
7	W10127710	Plate, Door Handle
8	2309056	Spacer, Door-Skin (Handle Side)
9	W10159602	Skin, Door
10		Screw
	8281250	Stainless Steel
11	2005433	Spacer, Door-Skin (Top)
12	488568	Screw
13	2004932	Spacer, Door-Skin (Bottom)
14	W10142296	Spacer, Door-Skin (Hinge Side)
15	W10127978	Filler, Door
17	W10323602	Bin, Door
18	W10168981	Stud, Handle
19	308544	Screw

UPPER UNIT PARTS

For Model: EF42NBSS03
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER UNIT PARTS


For Model: EF42NBSS03

(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	W10133449	Inverter Box	19	489399	Screw	<hr/> Following Parts Not Illustrated and Optional Parts Not Included <hr/>		
2	489373	Screw, Compressor Mounting	20	2155774	Wire Tie			
3	W10173296	Compressor (Includes Items 6 & 9)(Also Order 876765 Tube Kit)	21	W10175593	Drier			
4	2318087	Housing, Control Board	22	2310207	Wire Assembly (Condenser Fan)			
5	W10414681	Bracket, Fan Motor	23	2188875	Motor, Fan			
6	1100826	Grommet, Mounting	24	W10139483	Blade, Fan			
7	W10415668	Support, Condenser (Right)	25	W10415670	Orifice, Fan			
8	W10185556	Bracket, Switch	26	2307566	Tube, Drier Transition			
9	2215676	Terminal Cover	27	8533993	Screw			
10	W10415666	Support, Condenser (Left)	28	W10234131	Tube, Heat Loop Transition			
11	W10818296	Control Board, Gemini	29	2169104	Insulation, Sound	978025		Valve, Access (1/4")
12	2203075	Spacer	30	2309432	Gasket, Condenser	978026		Valve, Access (5/16")
13	2256328	Bracket, Inverter Box	31	2259350	Power Supply, Ingredient Care Center	978027		Valve, Access (3/8")
14	2317031	Bracket, Vibration Condenser	32	2194319	Process, Tube	978028		Valve, Access (1/2")
15	1157158	Screw	33	2309000	Cover, Condenser	978029		Valve, Access (5/8")
16	2307998	Condenser	34	2310251	Service Cord	978030		Valve, Access (3/4")
18	2317030	Arm, Vibration Condenser	35	486194	Screw	876764		Valve, Access (3/16")
			36	2266802	Switch, Power Disconnect	REFRIGERANT CHARGE 7.50 oz. (R-134A)		
			37	8281164	Screw, Ground			
			38	549193	Clamp, Cord			
			39	W10178883	Wiring Harness, Unit Compartment			

LOWER UNIT AND TUBE PARTS

For Model: EF42NBSS03
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


LOWER UNIT AND TUBE PARTS

For Model: EF42NBSS03
(Stainless Steel)

Illus.	Part	
No.	No.	DESCRIPTION
1	486194	Screw
2	W10157752	Bracket
3	W10431124	Suction Tube Oil Trap
4	W10388653	Tube, Connect (Drier/Restrictor)
5	W10281063	Drain Pan Assembly
6	W10316077	Cover, Wiring
7	W10321048	Cover, Box
8	W10412488	Tube, Discharge
9	W10427992	Evaporator
10	W10140161	Heater, Defrost
11	1113048	Clamp, Heater
12	W10139908	Seal, Return Air
13	W10432308	Gasket, Evaporator
15	W10169509	Clip, Heat Exchanger
16	2320554	Support, Drain Pan
18	W10160981	Bracket Assembly, Air Return
19	2215648	Dampener

ICEMAKER PARTS

For Model: EF42NBSS03
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Model: EF42NBSS03

(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	W10129653	Shield, Valve	16	2221070	Clamp Tube	33	W10281342	Module & Motor Assembly
2	2259064	Cover, Fill Tube Heater	17	2221240	Heater, Fill Tube	35	W10001250	Screw
3	W10377187	Wire Assembly, Icemaker	18	W10377174	Cover	36	486194	Screw
4	487539	Screw	19	W10372190	Shut Off Arm	100	W10435673	Complete Icemaker Assembly
5	628379	Clip, Fuse	20	W10122527	Mold & Heater (Also Order 542638 Silicone Grease)	<hr/> Following Parts Not Illustrated (Optional Parts Only)		
6	W10296807	Tube, Filter Inlet	21	W10372199	Shut Off Arm Assembly			
7	2314049	Water Inlet Tube Assembly	22	W10122568	Cup-water rim	W10355016	Affresh Stainless Steel Cleaner	
8	1106508	Seal Gasket	23	627843	Ejector	W10355010	Affresh Kitchen Appliance Cleaner	
9	2317912	Tube, Filter Outlet	24	W10122563	Ice Stripper Thermostat	W10355049	Affresh Stainless Steel Wipes	
10	2307650	Valve, Solenoid	27	627985	Thermostat (Also Order 542639 Cement Alumilastic)	REFDEODOR	Deodorizer Pack	
11	2304353	Extension, Shut Off Arm	29	2221231	Shield, Heat			
12	2221070	Clamp, Tube	31	W10279393	Wire Assembly (Water Valve)			
13	2310108	Jumper, Fill Tube Heater	32	W10141604	Screw			
14	2320559	Support, Valve						
15	2208136	Clamp, Nylon Valve						