


CABINET PARTS

For Model: EF48DBSS

(Stainless Steel)

48" BUILT IN
REFRIGERATOR



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS


For Model: EF48DBSS
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	11	103855	Cam, Door Closer	32		Skirt-Grille, Bottom
	W10159566	Use & Care Guide	12	2209022	Housing, Water Filter		2209026B	Black
	W10165112	Energy Guide				33		Extension Arm, Door Closer
	W10180103	Service & Wiring Sheet	13	103877	Clamp, Filter Housing		104096	Right
	2306424	Icemaker and Ingredient Care Center Service Sheet	14	104021	Screw		2266881	Left
			15	4396510	Filter, Water	34		Grille Bottom, Front
			16	104084	Screw		2209431B	Black
	W10180893	Main Control Service Sheet	17	3400230	Screw, Door Stop	35	104022	Screw
	W10159564	Installation Instructions	18	103904	Hinge (Top)	36		Bracket, Support Base (Front)
			19	103944	Bracket, Mtg (Water Filter)		2006616	Left
			20	104085	Screw		2006556	Right
2		Cabinet (Not A Serviceable Part)	21	2004994	Lock, Adjustable Bushing	37	103849	Screw
4	104052	Roller, Front & Rear (4)	22	2300082	Bushing	38	103861	Bracket, Support Base (Rear) (2)
5		Support, Leveler Assembly				39	103858	Washer
	104002	Refrigerator Side		2221242	Right Side	40	103907	Bushing, Extension Arm
	104001	Freezer Side		103853	Left Side	41	103850	Screw
6	2005032	Leveler, Adjustable (2)	25	104072	Screw	42		Connector, Water Tube
7	103862	Ring, Retaining (2) Flexible	26	2005008	Retaining Ring, Adjustable Bushing		2209709	5/16-1/4"
			27	104044	Wire Clip (5)		2300868	1/4"
8		Cap, Water Filter	28	2006342	Gap, Cover Assembly (Bottom)	44		Switch, Rocker Arm
	104032	Black	29		Hinge (Bottom)		103848	Refrigerator Door Side
9	104104	Mounting Stud, Grille		2006780	Freezer Side		1115373	Freezer Door Side
				2006779	Refrigerator Side	45	2215938	Cover, Switch (2)
10	103945	Grommet, Crossover Tube	30	2302876	Bushing, Adjustable	46	487415	Screw (2)
			31	104025	Screw 1/4-20 x 5/8	47		Bracket, Switch
							2221097	Right
							2221096	Left
						48	2215612	Cover, Rear

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET TRIM PARTS

For Model: EF48DBSS
(Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1		Cabinet, Trim (Right Side)
	W10132472	Stainless Steel
3		Screw
	1163283	Stainless Steel
4	2316688	Cabinet, Trim (Bottom)
5	486194	Screw
6	2314018	Cabinet, Trim Top
7		Cabinet Trim (Left Side)
	W10132541	Stainless Steel
8	W10121451	Nutsert (4)
9	2005925	Seal-Trim, Side
10	489464	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER SHELF PARTS

For Model: EF48DBSS
(Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	2302869	Wire, Shelf (4)
3	2302884	Shelf, Fixed (2)
4	2259083	Basket
5	2256271	Front, Basket
6	2259317	Slide, Basket
	2259318	Right Side
	2259318	Left Side
7	8533928	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR LINER PARTS

For Model: EF48DBSS
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR LINER PARTS


For Model: EF48DBSS
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2306010	Thermistor
3	2208970	Air Duct
4	2003577	Guard, Air Return
5	2259077	Ladder, Shelf (2)
6	520965	Screw Support, Ladder (8)
7	2006475	Screw
8	487539	Screw
9	2302937	Thermistor
10	2302986	Lid, Meat Pan Baffle
11	W10169528	Baffle Control Assembly
12	2171846	Release Valve
13	2310205	Jumper, Air Baffle
14	488357	Screw
15	486194	Screw
17	2221296	Air Baffle Assembly
18	2327509	Reservoir
19	488280	Screw
21	2309222	Diffuser Assembly
22	2317105	Cover, Thermistor
23	2188820	Thermistor
24	2302992	Spacer, Air-Baffle
25	2309087	Cover, Diffuser
27	2259412	Seal, Air Duct (Round Hole)
28	2259398	Seal, Air Duct (Square Hole)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Model: EF48DBSS
(Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	2302773	Control Box
2	2215670	Insert, Control Box
3	2310197	Wire Assembly, UI Control
4	106428	Circuit Board, Control Box Housing Control
5	2221121	Support, Control Box
6	489006	Screw (2)
7	W10151210	Display, Ingredient Care Center
8	2162085	Socket, Light
9	2255743	Light Bulb (2)
10	8281185	Screw
11	W10165031*	Overlay, Control *106897 (Dacor P/N) Box
12	2302716	Shield, Light
13	486194	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP GRILLE AND UNIT COVER PARTS

For Model: EF48DBSS
(Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1		Panel, Decorative Assembly
	W10162621	Stainless Steel
2	W10161693	Cover, Unit
3	486194	Screw
4	2256466	Back Panel
5	W10121229	Cover, Unit Front
6	487415	Screw
7	2310194	Wire Assembly RC/FC Light Switch
8	12989001	Badge, Dacor
9	489348	Clamp
11	2215910	Grommet, Flexible

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS

For Model: EF48DBSS
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS


For Model: EF48DBSS
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	W10165104	Shelf Assembly (4)
3	W10165092	Assembly, Meat Pan Cover
4	107913	Assembly, Crisper Cover
5	2257583	Trim, Glass Rear
6	2252413	Crisper Pan (2)
7		Slide, Meat Pan
	2302954	Left Side
	2302955	Right Side
8		Trim, Glass Front (Not Serviceable)
9	2256255	Trim, Glass Rear
10	2256249	Front, Crisper Pan
11	2252255	Trim, Glass Side Crisper Pan
12	2256250	Trim, Glass Side Meat Pan
13		Spacer, Crisper
	2256222	Right Side (2)
	2256223	Left Side (2)
14		Slide, Crisper
	2302956	Right Side
	2302957	Left Side
15		Spacer, Meat Pan
	2256243	Left Side
	2256244	Right Side
16		Screw
	8533929	Right Side- (8-18 x 1.375)
	8533928	Left Side- (8-18 x .750)
17	2256370	Pan Assembly Meat
18	2256367	Front, Meat Pan

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER AND AIR FLOW PARTS

For Model: EF48DBSS
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER AND AIR FLOW PARTS


For Model: EF48DBSS
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	2259385	Fan Motor	18		Block, Fan Scroll	32	2220904	Gasket (2)
2	2198665	Tube, P.C. Board		2209482	Right			Evaporator Cover
3	2169142	Fan Blade		2209066	Left	33	W10151208	Cover, Receiver
4	2223733	Retainer, Fan Motor	19	W10151205	Cover, Emitter	34	W10139189	Harness, Evap Fan (Includes Item 45)
5	2302817	Gasket, Cover	20		Liner (Not A Serviceable Part)	35	2306010	Thermistor
6	2223986	Grommet	21	2259025	Cover, Air Outlet	36	2317105	Cover, Thermistor
7	486194	Screw	22	2307751	Light Shield	37	2006475	Screw
8	2259464	Wedge, Air Duct	23	W10158005	Cover, Evaporator	38	2259032	Ladder, Shelf
9	488500	Screw, Ground	24	2302851	Support, Air Duct	39	2259445	Support, Screw
10	2223857	Socket, Light (2)	25	487539	Screw	40	2198634	Pin
11	488937	Clamp, Nylon	26	2198635	Spring	41	2220398	P.C. Board
12	2326255	Light Bulb	27	2309284	Deflector, Air Duct	42	2198633	Flipper
13	489214	Screw	28	1112260	Support, Evaporator	43	2315398	Slide, Icemaker Shut Off
14	2182120	Scroll, Fan	29	2196483	Shelf, Stud (20)	44	2255114	P.C. Board, Receiver
15	2259465	Wedge, Air Duct	30	8281158	Screw	45	W10160570	Defrost, Bi-Metal
16	2307775	Air Duct	31		Evaporator, Cover Rail	46	8281185	Screw
17	2198643	Lens		2221107	Left Side			
				2259355	Right Side			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND ICE CONTAINER PARTS

For Model: EF48DBSS
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND ICE CONTAINER PARTS


For Model: EF48DBSS
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	2222970	Ice Bin
2	W10151248	Crusher Bin
3	W10140642	Auger
4	2258220	Washer, Auger
5	1119007	Spacer, Flat (6)
6	2317248	Cover, Crusher
7	2257024	Blade, Rotary
8	1119005	Spacer, Step (2)
9	2257020	Blade, Fixed
10	2257023	Blade, Rotary
11	2317239	Block, Blade
12	489229	Roll Pin
13	2257022	Blade, Rotary
14	489235	Washer, Plain
15	2198661	Washer, Coupling
16	2188918	Coupling, Top
17	8281164	Screw
18	3400065	Screw
19	2266800	Button, Bin
20	W10134785	Latch, Bin
21	2198608	Spring, Latch
22	2198671	Screw (2)
23	8281163	Screw
24	2188919	Holder
25	2198628	Seal
26	2318030	Drive Shaft
27	2318011	Enclosure, Motor
28	2315546	Dispenser, Motor
29	2318028	Cover
30	2315559	Sleeve, Coupling
31	2317250	Divider, Chamber
32	2317243	Wiper
33	108810	Wiring Harness Dispenser Motor (not shown)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Model: EF48DBSS
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS


For Model: EF48DBSS
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	2252331	Refrigerator Door Panel (Includes Item #9)
2	2258951	Brace, Door Corner
3	2266854	Hinge Assembly, Top
4	2316804	Spacer-Door, Top & Bottom
5	489282	Screw
6	2302878	Hinge Assembly, Bottom
7	2222797	Rail, Lid
8	2222983	Gasket, Utility Bin
9	2222812	Door Gasket, Magnetic Skin, Door
10		
	LW10121043	Stainless Steel
12		Spacer, Door-Skin (Handle Side)
	2309060	For Stainless Steel Model
13	W10153450	Stud, Handle
14	488568	Screw
15		Screw, 8-15 x .500
	8281250	Stainless Steel
16	2005433	Spacer, Door-Skin (Top)
17	308544	Screw, Handle
18	2005030	Spacer, Door-Skin (Hinge Side)
19	2004935	Spacer, Door-Skin (Bottom)
20	2005327	Filler, Door
21		End Cap
	2222919	Right Side
	2222920	Left Side
22	W10127710	Plate, Door-Handle
23	2222923	Bin, Utility Center
24	2257617	Door, Utility Bin
25	2222774	Bin, Door (3)
26	2222771	Bin, Door

FREEZER DOOR PARTS

For Model: EF48DBSS

(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS


For Model: EF48DBSS
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	W10197698*	Freezer Door (Includes #6)
2	2302879	Hinge, Bottom
3	489282	Screw
4	2266854	Hinge, Top
5	2316804	Spacer-Door, Top & Bottom
6	2222810	Door Gasket, Magnetic
7	W10153450	Stud, Handle
8		Spacer, Door-Skin (Handle Side)
	2309060	For Stainless Steel Model
9		Skin, Door
	W10197700	Stainless Steel
10		Screw
	8281250	Stainless Steel
11	2005433	Spacer, Door-Skin (Top)
12	488568	Screw
13	2257386	Spacer, Door-Skin (Bottom)
14	2005030	Spacer, Door-Skin (Hinge Side)
15	308544	Screw, Handle
16		Filler, Door
	W10159586	Top
	W10159583	Bottom
17	2258951	Brace, Door Corner
18	2222777	Bin, Door (3)
19	W10127710	Plate, Door Handle

*Dacor # 106603

DISPENSER FRONT PARTS

For Model: EF48DBSS
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISPENSER AND FRONT PARTS


For Model: EF48DBSS
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviced)
2	2195051	Strain Relief
3	W10139147	Wire Assembly
4		Cover, Dispenser (Not Serviced)
5	2304772	Spring, Torsion
6	2196195	Pin
7	2304355	Ice Door Mechanism
8	2180353	Door, Ice
9	489000	Screw
10	2259396B	Lever, Ice
11		Switch Assembly (Not Available, Order #25)
12	2259395B	Lever, Water
13	2194719	Spring, Lever
14	2205686	Delay Mechanism
15	2183771	Bracket, Control
16	2162361	Switch (2)
17	2259209	Bracket, Anti Drip Valve
18	2180200	Lamp Holder
19	488500	Screw
20	2310198	Harness, Switch
21	2180224	Guide, Ice
22	3406124	Light Bulb
23	2302944B	Grill, Overflow
24		Overlay, Cover (Not Serviced)
25	W10165055	Front Cover Assembly (Includes 4,11,20, & 24)
26	2306077	Spacer, Dispenser Cover
27	2320669	Valve, Anti Drip
28	2252127	Sleeve, Delay Mechanism

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER UNIT PARTS

For Model: EF48DBSS
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER UNIT PARTS

For Model: EF48DBSS
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	W10133449	Inverter Box
2	489373	Screw, Compressor Mounting (4)
3	2223393	Compressor (Includes Items 6 & 9)(Also Order 876765 Tube Kit)
4	2318087	Housing, Control Board
6	1100826	Grommet, Mounting
7	2309002	Support, Conenser
8	2307694	Tube, Transiton (Cond/Ht Loop) (Right)
9	2215676	Terminal Cover
10	2309001	Support, Condenser (Left)
11	2307028	Control Board
12	2203075	Spacer (5)
13	2256328	Bracket, Inverter Box
14	486194	Screw
15	1157158	Screw
16	2307998	Condenser
17	2309431	Grommet (2)
18	2310207	Wire, Jumper
19	489399	Screw

Illus. No.	Part No.	DESCRIPTION
20	2155774	Wire Tie
21	2317982	Drier
22	W10136614	Bracket, Fan Motor (Condenser Fan)
23	2188875	Motor, Fan
24	W10139483	Blade, Fan
25	2003169	Orifice, Fan
27	8533993	Screw
28	2317031	Bracket, Vibration (Condenser)
29	2317030	Arm, Vibration (Condenser)
30	2307566	Tube, Transition (Condenser/Drier)
31	2194319	Tube, Process
32	486194	Screw
33	2309000	Cover, Condenser
34	2310251	Service Cord
35	2307684	Bracket, Mounting (Power Switch)
36	549193	Clamp, Cord
37	2266802	Switch, Power Disconnect
38	487294	Screw, Ground
39	W10167450	Wiring Harness, Unit Compartment
40	2309432	Gasket, Condenser
41	2259350	Power Supply, Ingredient Care Center

Illus. No.	Part No.	DESCRIPTION
Following Parts Not Illustrated and Optional Parts Not Included		
	978025	Valve, Access (1/4")
	978026	Valve, Access (5/16")
	978027	Valve, Access (3/8")
	978028	Valve, Access (1/2")
	978029	Valve, Access (5/8")
	978030	Valve, Access (3/4")
	876764	Valve, Access (3/16")

REFRIGERANT CHARGE

7.75 oz.
(R-134A)

LOWER UNIT AND TUBE PARTS

For Model: EF48DBSS
(Stainless Steel)


<u>Illus. No.</u>	<u>Part No.</u>	<u>DESCRIPTION</u>
1	9791833	Clip
2	486194	Screw
3	W10157752	Bracket
4	2309076	Suction Tube
5	2309070	Tube, Connect (Drier/Restrictor)
6	2320615	Drain Pan Assy.
7	W10151288	Cover, Wiring
8	W10153595	Cover, Box
9	W10121374	Tube, Discharge
10	2188820	Thermistor
11	2306094	Evaporator
12	W10140162	Heater, Defrost
13	1113048	Clamp, Heater (2)
14	W10139908	Seal, Return Air
15	2220832	Gasket, Evaporator
16	2155774	Wire Tie
17	W10169509	Clip, Heat Exchanger
18	2320554	Support, Drain Pan
19	2215648	Dampener
20	W10160981	Bracket Assembly, Air Return
21	489464	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Model: EF48DBSS

(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Model: EF48DBSS
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
2	W10129655	Shield, Valve
3	2310191	Wire Assembly, Icemaker
5	628379	Clip, Fuse
6	2325170	Tube, Filter Inlet
7	2320658	Water Tube
8	2302758	Seal Gasket
9	2317912	Tube, Filter Outlet
10	2317883	Valve, Solenoid
12	2221070	Clamp, Tube
13	2320559	Support, Valve
14	2198641	Bracket, Icemaker Cover
15	2305274	Clamp, Nylon Valve
17	2302756	Tube, Water Inlet
18	2221232	Cover
19	488500	Screw

Illus. No.	Part No.	DESCRIPTION
20	W10122527	Mold & Heater (Also Order 542638 Silicone Grease)
21		Motor, (Not Serviceable Order Item 32)
22	628356	Cup-Water Fill
23	627843	Ejector
24	2198598	Ice Striper
25	2194712	Support
26	2315522	Retainer Thermostat (2)
27	628397	Thermostat (Also Order 542639 Cement Alumilastic)
28	8533917	Screw
29	W10139193	Wire Assembly, Water Valve
30	489276	Screw

Illus. No.	Part No.	DESCRIPTION
31	W10151256	Cover, Icemaker
32	626680	Module Assembly (Includes Items 21 & 33)
33	489136	Screw (2)
34	489464	Screw
35	486194	Screw
36	2252228	Bracket, Icemaker Mounting
100	W10122509	Complete Icemaker Assembly

Following Parts Not Illustrated
(Optional Parts Only)

8537055	Cleaner, Stainless Steel
W10151246	Ice Container Assembly