



LET THE SHOW BEGIN


# PARTS CATALOG

## HWHP3012/3018, HWEP3012/3018 Heritage 30" Pro Range Wall Hoods

Assembly Drawings	
Click Page	Description
<a href="#">2</a>	HWHP3012/3018 Hood Assembly
<a href="#">4</a>	HWHE3012/3018 Hood Assembly
<a href="#">6</a>	Inner Assembly

# HWHP3012/HWHP3018 Hood Assembly

HWHP3012 Shown (parts list next page)




[Return to Page 1](#)

## HWHP3012/HWHP3018 Hood Assembly Parts List

Item	HWHP3012 PN	HWHP3018 PN	Description
1	Not serviceable	Not serviceable	ASSY, CANOPY
2	702452	702423	ASSY, CANOPY, MTG BRKT
3	702453	702718	ASSEMBLY, BLOWER
4	702446AH-01	702446AH-01	ASY, LINER, 30"
5	702469	703003	WELD, INTERIOR PANEL
6	702871	702871	ASSY, 30" REAR LINER
7	702865	702865	WELDMENT, 30" GREASE TRAY
10	101613	101613	COLLAR, DAMPER
11	109144	109114	FRAME, SIDE
12	110148-01	110148-01	TRIM, 30", LH
13	110148-02	110148-02	TRIM, 30", RH
19	102373	102373	SCREW, #8-18 X 1/4"
20	83167	83167	CLAMP, CABLE 3/4"
21	83056	83056	BUSHING HEYCO SB-875-11
22	83308	83308	6-32 KEPS NUT
28	109109	109109	KNOB, BAFFLE
29	109328	109328	SCREW 8-32 X 5/16" PHIL PAN HD
30	83340	83340	#10 LOCK WASHER
31	702495	702495	WELDMENT, BAFFLE

[Return to Page 1](#)

# HWHE3012/HWHE3018 Hood Assembly




## HWHE3012/HWHE3018 Hood Assembly

Item	HWHP3012 PN	HWHP3018 PN	Description
1	Not serviceable	Not serviceable	ASSY, 48X12/18 CANOPY
2	702422-01FAH	702422-01FAH	ASSY, 48IN LINER, RNHP
3	702423	702452	ASSY, CANOPY MTG BRKT
4	702424	702457	WELDMENT, 48X12IN INTERIOR PNL
5	702425	702425	ASSY, 48 REAR LINER
6	702426	702426	ASSY, 30" REAR LINER
7	702718	702453	WELDMENT, 48IN GREASE TRAY
8	101613	101613	COLLAR, DAMPER
9	702493	702493	ASSY, TERMINAL BLOCK PLATE
10	702494-01	702494-01	ASSY, CONTROLLER
11	109144	109144	FRAME, SIDE
12	109123-01	109123-01	TRIM, 48IN, LH
13	109123-02	109123-02	TRIM, 48IN, RH
14	109072	109072	HARNESS, MAINWIRE, 2-FAN
15	109077	109077	HARNESS, 4-LIGHT HOOD WIRE
16	83308	83308	6-32 KEPS NUT
17	83263	83263	SCREW, PHILL, ROUND WASHER, HD
18	83534	83534	SCREW, #8 x .375, ENAMEL PANEL
19	102373	102373	SCREW, #8-18 X 1/4"
20	83167	83167	CLAMP, CABLE 3/4"
21	83056	83056	BUSHING HEYCO SB-875-11
22	83334	83334	STARWASHER, #8
23	83035	83035	NUT, WING, #10-24
24	83530	83530	SCREW, PHIL. PAN HD, 4-40 X .625 LG
25	83531	83531	NUT, HEX, KEPS 4-40
26	83001	83001	SCREW, PHIL PAN HD, 8 X 1/4"
27	702495	702495	WELDMENT, BAFFLE
28	109253	109253	LIGHT, LED

# HWHP3012/HWHP3018 Inner Assembly

HWHP3012 Shown (parts list next page)



Return to Page 1

## HWHP3012/HWHP3018 Inner Assembly Parts List

Item	HWHP3012 PN	HWHP3018 PN	Description
4	702446AH-01	702446AH-01	ASY, LINER, 30"
5	702469	703003	WELD, INTERIOR PANEL
8	702493	702493	ASSY, TERMINAL BLOCK PLATE
9	702494-01	702494-01	ASSY, CONTROLLER
14	109071	109071	HARNESS, MAIN WIRE, 1-FAN
15	109075	109075	HARNESS, 2-LIGHT HOOD WIRE
16	109075	109075	HARNESS, 2-LIGHT HOOD WIRE
17	83263	83263	SCREW, PHILL, ROUND WASHER, HD.
18	83534	83534	SCREW, #8 X .375, ENAMEL PANEL
23	83334	83334	STARWASHER, #8
24	83035	83035	NUT, WING, #10-24
25	83001	83001	SCREW, PHIL PAN HD, 8 x 1/4"
26	83530	83530	SCREW, PHIL. PAN HD, 4-40 X .625 LG
27	83531	83531	NUT, HEX, KEPS 4-40
32	109253	109253	LIGHT, LED
33	703582	703582	ASSY, CTRL PANEL, WHITE
34	113701	113701	PUSH BUTTON SWITCH, WHITE
35	113789	113789	HARNESS, CTRL PANEL WIRE
36	P/O 113701	P/O 113701	JAM NUT
37	107578	107578	SCREW BP, PHIL, FLT HD, TYPE 1
38	101624	101624	LAMP HOLDER
39	109355S	109355S	TRIM, LAMP, HOODS

[Return to Page 1](#)