



# CABINET PARTS


For Model: EF42NBSS03  
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	10	2209022	Housing, Water Filter	30		Grille Bottom, Front
	W10303784	Use & Care Guide	11	3400525	Screw		2209428B*	Black
	W10205629	Energy Guide	12	W10168990	Filter, Water	31	W10004850	Screw
	W10180102	Service & Wiring Sheet	13	489399	Screw	32		Bracket, Support Base (Front)
	2306337	Icemaker and Ingredient Care Center	14	2005378	Screw, Door Stop		2006616	(LH)
		Service Sheet	15	2257644	Hinge (Top)		2006556	(RH)
	W10180891	Main Control Service Sheet	16	W10348781	Bracket, Mount (Water Filter)	33	1157158	Screw
	W10379135	Installation Instructions	17	W10001250	Screw	34	2006617	Bracket, Support Base (Rear)
2		Cabinet (Not A Serviceable Part)	18	W10451421	Lock, Adjustable Bushing	35	2006346	Washer
3	2209090	Clamp, Filter Housing	19	2300082	Bushing	36	2316859	Bushing, Extension Arm
4	W10138054	Roller, Front & Rear	20	2221242	Spring, Door Closure	37	1163283	Screw
5		Support, Leveler Assembly	21	486194	Screw	38	8281163	Screw
	W10138423	Refrigerator Side	22	2005008	Retaining Ring, Adjustable Bushing	39	2005032	Leveler, Assy
	W10279275	Freezer Side	23	W10129069	Wire Clip	40		Switch, Rocker Arm
6		Cap, Water Filter	24	W10406421	Gap, Cover Assembly (Bottom)		1118894	Refrigerator Door Side
	2186494B	Black	25		Hinge (Bottom)		1115373	Freezer Door Side
7	2325157	Bracket, Grill Mounting		W10424756	Freezer Side	41	2215938	Cover, Switch
8	2307584	Grommet, Crossover Tube		W10424754	Refrigerator Side	42	487415	Screw
9	2005783	Cam, Door Closer	26	2302876	Bushing, Adjustable	43		Bracket, Switch
			27	8533913	Screw 1/4-20 x 5/8		2221097	(RH)
			28		Skirt-Grille, Bottom		2221096	(LH)
				2209025B	Black	44	2215612	Cover, Rear
			29		Extension Arm, Door Closer	45	2006841	Ring, Retainer
				2266882	(RH)	46	2307857	Cam Assembly
				2266881	(LH)	47	W10167456	Wire Assembly RC/FC Light Switch

\* Some units are equipped with a tear-drop shaped filter access hole (not shown) to allow access to the switch behind. Replace this type of grille with part number 2325185B.

# CABINET TRIM PARTS

For Model: EF42NBSS03  
(Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	W10132472	Cabinet, Trim (Right Side)
3	1163283	Screw
4	2316687	Cabinet, Trim (Bottom)
5	486194	Screw
6	2314017	Cabinet, Trim Top
7	W10132541	Cabinet Trim (Left Side)
8	W10121451	Nutsert
9	2005925	Seal-Trim, Side
10	W10001250	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# FREEZER SHELF PARTS

For Model: EF42NBSS03  
(Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

1	W10175905	Wire, Shelf
2	W10213534	Cover, Shelf
3	2302883	Shelf, Fixed
4	2259082	Basket
5	2256270	Front, Basket
6		Slide, Basket
	2259317	(RH)
	2259318	(LH)
7	8533928	Screw
8	2266934	Door, Ice
9	2266931	Bucket, Ice
10	2266955	Spacer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST




# REFRIGERATOR LINER PARTS

For Model: EF42NBSS03  
(Stainless Steel)

<b>Illus. No.</b>	<b>Part No.</b>	<b>DESCRIPTION</b>
1		Liner (Not A Serviceable Part)
2	2306010	Thermistor
3	2208970	Air Duct
4	2003577	Guard, Air Return
5	2259077	Ladder, Shelf
6	520965	Screw Support, Ladder
7	2006475	Screw
8	487539	Screw
9	2302937	Thermistor
10	2302986	Lid, Air Baffle
11	W10169528	Baffle, Control Assembly
12	2317844	Thermistor Assy
13	2310205	Jumper, Air Baffle
14	487539	Screw
15	486194	Screw
16	2221296	Air Baffle Assembly
17	2309222	Diffuser Assembly
18	2317105	Cover, Thermistor
19	2188820	Thermistor
20	2302992	Spacer, Air-Baffle
21	2309087	Cover, Diffuser
22	2259412	Seal, Air Duct (Round Hole)
23	2259398	Seal, Air Duct (Square Hole)
24	W10159487	Diverter, Crisper Cover

# CONTROL PANEL PARTS

For Model: EF42NBSS03  
(Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	2302772	Control Box
2	2215670	Insert, Control Box
3	2310197	Wire Assembly
4	106428	Circuit Board, Housing Control
5	2221121	Support, Control Box
6	487539	Screw
7	W10151210	Display Board, Ingredient Care Center
8	2162085	Socket, Light
9	W10311505	Light Bulb
10	W10142283	Screw
11	W10165030	Overlay, Control Box
12	2302717	Shield, Light
13	486194	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TOP GRILLE AND UNIT COVER PARTS

For Model: EF42NBSS03  
(Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

- |   |           |                   |
|---|-----------|-------------------|
| 1 | W10162620 | Panel, Decorative |
| 2 | W10161693 | Cover, Unit       |
| 3 | 486194    | Screw             |
| 4 | 2256466   | Back Panel        |
| 5 | W10185625 | Cover, Unit Front |
| 6 | 12989001  | Nameplate         |
| 7 | 489399    | Screw             |
| 8 | 2215910   | Grommet           |



# REFRIGERATOR SHELF PARTS

For Model: EF42NBSS03  
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# REFRIGERATOR SHELF PARTS

For Model: EF42NBSS03  
(Stainless Steel)

<b>Illus. No.</b>	<b>Part No.</b>	<b>DESCRIPTION</b>
1	W10165103	Shelf Assy
2	W10165091	Meat Pan Cover Assembly
3	W10165085	Crisper Cover Assembly
4	W10407624	Crisper Pan
5		Slide, Meat Pan
	2302954	(LH)
	2302955	(RH)
6	2256248	Front, Crisper Pan
7		Spacer, Crisper
	2256222	(RH)
	2256223	(LH)
8		Slide, Crisper
	2302957	(RH)
	2302956	(LH)
9		Spacer, Meat Pan
	2256243	(LH)
	2256244	(RH)
10	8533929	Screw
11	W10407627	Pan Assembly Meat
12	2256366	Front, Meat Pan




# FREEZER LINER AND AIR FLOW PARTS

For Model: EF42NBSS03  
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	2259385	Fan Motor
2	2169142	Fan Blade
3	2223733	Retainer, Fan Motor
4	2302817	Gasket, Cover
5	W10449920	Grommet
6	486194	Screw
7	2259464	Wedge, Air Duct
8	W10141604	Screw, Ground
9	W10191429	Socket, Light
10	2221070	Clamp, Nylon
11	2326255	Light Bulb
12	2182120	Scroll, Fan
13	2259465	Wedge, Air Duct
14	2266801	Deflector, Air
15	2307777	Air Duct
16	2209480	Block, Fan Scroll (RH)
	2209066	(LH)
17		Liner (Not A Serviceable Part)
18	2259025	Cover, Air Outlet
19	2307751	Light Shield
20	W10428000	Cover, Evaporator
21	8281163	Screw
22	2302850	Support, Air Duct
23	2309283	Deflector, Air Duct
24	1112260	Support, Evaporator
25	W10173127	Shelf, Stud
26	W10191952	Screw
27		Evaporator, Cover Rail
	2221107	(LH)
	2259355	(RH)
28	2220904	Gasket Evaporator Cover
29	W10139189	Harness, Evap Fan (Includes Item 36)
30	W10267707	Insulation, Sound
31	2188820	Thermistor
32	2317105	Cover, Thermistor
33	2006475	Screw
34	2259032	Ladder, Shelf
35	2259445	Support, Screw
36	W10160570	Defrost, Bi-Metal
37	W10142283	Screw
38	2317844	Thermistor Assy

# REFRIGERATOR DOOR PARTS

For Model: EF42NBSS03  
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


# REFRIGERATOR DOOR PARTS

For Model: EF42NBSS03  
(Stainless Steel)

<b>Illus.</b>	<b>Part</b>	
<b>No.</b>	<b>No.</b>	<b>DESCRIPTION</b>
1	W10193490	Refrigerator Door (Includes #9)
3	2266854	Hinge Assembly, Top
4	2316804	Spacer-Door, Top & Bottom
5	W10162602	Screw
6	2302878	Hinge Assembly, Bottom
7	2222796	Rail, Lid
8	2222982	Gasket, Utility Bin
9	2222811	Door Gasket, Magnetic
10	W10159605	Skin, Door
11	W10127710	Plate, Door Handle
12	2309060	Spacer, Door (Handle Side)
13	488568	Screw
14	8281250	Screw, 8-15 x .500 Stainless Steel
15	2005433	Spacer, Door-Skin (Top)
16	W10142296	Spacer, Door (Hinge Side)
17	2004934	Spacer, Door-Skin (Bottom)
18	W10127977	Filler, Door
19		End Cap (RH) (LH)
20	W10323172 W10323173 W10323036	Bin, Utility Center
21	2257616	Door, Utility Bin
22	W10323599	Bin, Door
23	W10323747	Bin, Gallon
24	W10168981	Stud, Handle
25	308544	Screw

# FREEZER DOOR PARTS

For Model: EF42NBSS03  
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# FREEZER DOOR PARTS


For Model: EF42NBSS03  
(Stainless Steel)

<b>Illus.</b>	<b>Part</b>	
<b>No.</b>	<b>No.</b>	<b>DESCRIPTION</b>
1	W10193486	Freezer Door
2	2302879	Hinge, Bottom
3	W10162602	Screw
4	2266854	Hinge, Top
5	2316804	Spacer-Door, Top & Bottom
6	2222814	Door Gasket, Magnetic
7	W10127710	Plate, Door Handle
8	2309056	Spacer, Door-Skin (Handle Side)
9	W10159602	Skin, Door
10	8281250	Screw Stainless Steel
11	2005433	Spacer, Door-Skin (Top)
12	488568	Screw
13	2004932	Spacer, Door-Skin (Bottom)
14	W10142296	Spacer, Door-Skin (Hinge Side)
15	W10127978	Filler, Door
17	W10323602	Bin, Door
18	W10168981	Stud, Handle
19	308544	Screw



# UPPER UNIT PARTS

For Model: EF42NBSS03  
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# UPPER UNIT PARTS

For Model: EF42NBSS03  
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	W10133449	Inverter Box
2	489373	Screw, Compressor Mounting
3	W10173296	Compressor (Includes Items 6 & 9)(Also Order 876765 Tube Kit)
4	2318087	Housing, Control Board
5	W10414681	Bracket, Fan Motor
6	1100826	Grommet, Mounting
7	W10415668	Support, Condenser (Right)
8	W10185556	Bracket, Switch
9	2215676	Terminal Cover
10	W10415666	Support, Condenser (Left)
11	W10219463	Control Board, Gemini
12	2203075	Spacer
13	2256328	Bracket, Inverter Box
14	2317031	Bracket, Vibration Condenser
15	1157158	Screw
16	2307998	Condenser
18	2317030	Arm, Vibration Condenser

Illus. No.	Part No.	DESCRIPTION
19	489399	Screw
20	2155774	Wire Tie
21	W10175593	Drier
22	2310207	Wire Assembly (Condenser Fan)
23	2188875	Motor, Fan
24	W10139483	Blade, Fan
25	W10415670	Orifice, Fan
26	2307566	Tube, Drier Transition
27	8533993	Screw
28	W10234131	Tube, Heat Loop Transition
29	2169104	Insulation, Sound
30	2309432	Gasket, Condenser
31	2259350	Power Supply, Ingredient Care Center
32	2194319	Process, Tube
33	2309000	Cover, Condenser
34	2310251	Service Cord
35	486194	Screw
36	2266802	Switch, Power Disconnect
37	8281164	Screw, Ground
38	549193	Clamp, Cord
39	W10178883	Wiring Harness, Unit Compartment

Illus. No.	Part No.	DESCRIPTION
Following Parts Not Illustrated and Optional Parts Not Included		


978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")
876764	Valve, Access (3/16")

## REFRIGERANT CHARGE

7.50 oz.  
(R-134A)

# LOWER UNIT AND TUBE PARTS

For Model: EF42NBSS03  
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


# LOWER UNIT AND TUBE PARTS

For Model: EF42NBSS03  
(Stainless Steel)

<b>Illus.</b>	<b>Part</b>	
<b>No.</b>	<b>No.</b>	<b>DESCRIPTION</b>
1	486194	Screw
2	W10157752	Bracket
3	W10431124	Suction Tube Oil Trap
4	W10388653	Tube, Connect (Drier/Restrictor)
5	W10281063	Drain Pan Assembly
6	W10316077	Cover, Wiring
7	W10321048	Cover, Box
8	W10412488	Tube, Discharge
9	W10427992	Evaporator
10	W10140161	Heater, Defrost
11	1113048	Clamp, Heater
12	W10139908	Seal, Return Air
13	W10432308	Gasket, Evaporator
15	W10169509	Clip, Heat Exchanger
16	2320554	Support, Drain Pan
18	W10160981	Bracket Assembly, Air Return
19	2215648	Dampener

# ICEMAKER PARTS

For Model: EF42NBSS03  
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# ICEMAKER PARTS

For Model: EF42NBSS03  
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	W10129653	Shield, Valve
2	2259064	Cover, Fill Tube Heater
3	W10377187	Wire Assembly, Icemaker
4	487539	Screw
5	628379	Clip, Fuse
6	W10296807	Tube, Filter Inlet
7	2314049	Water Inlet Tube Assembly
8	1106508	Seal Gasket
9	2317912	Tube, Filter Outlet
10	2307650	Valve, Solenoid
11	2304353	Extension, Shut Off Arm
12	2221070	Clamp, Tube
13	2310108	Jumper, Fill Tube Heater
14	2320559	Support, Valve
15	2208136	Clamp, Nylon Valve

Illus. No.	Part No.	DESCRIPTION
16	2221070	Clamp Tube
17	2221240	Heater, Fill Tube
18	W10377174	Cover
19	W10372190	Shut Off Arm
20	W10122527	Mold & Heater (Also Order 542638 Silicone Grease)
21	W10372199	Shut Off Arm Assembly
22	W10122568	Cup-Water Fill
23	627843	Ejector
24	W10122563	Ice Stripper Thermostat
27	627985	Thermostat (Also Order 542639 Cement Alumilastic)
29	2221231	Shield, Heat
31	W10279393	Wire Assembly (Water Valve)
32	W10141604	Screw

Illus. No.	Part No.	DESCRIPTION
33	W10281342	Module & Motor Assembly
35	W10001250	Screw
36	486194	Screw
100	W10435673	Complete Icemaker Assembly

---

Following Parts Not Illustrated  
(Optional Parts Only)

---

W10355016	Affresh Stainless Steel Cleaner
W10355010	Affresh Kitchen Appliance Cleaner
W10355049	Affresh Stainless Steel Wipes
REFDEODOR	Deodorizer Pack